

DRILLING TEMPLATE · GRAIN



TOP EDGE OF CLOCK (380 mm wide)

← 190 mm to
outer edge (left)

190 mm to →
outer edge (right)

110 mm



DRILL POINT Ø 6 mm

Wall bracket + retaining screw · hole depth approx. 45 mm (concrete/brick)



HOW TO USE THIS TEMPLATE

1. Hold the sheet against the wall: the «**Top edge of clock**» line marks where the clock ends at the top (clock centre = 190 mm below).
2. Align horizontally with a spirit level, fix with tape in the four fields.
3. Transfer the drill point through the crosshair with a pencil or centre punch.
4. Remove the template, drill Ø 6 mm, insert plug, fit the wall bracket — continue with the mounting instructions (TT-GRAIN-MI-EN), step 4.

⚠ BEFORE DRILLING

Check the print: the control dimension above must measure **exactly 100 mm** (print setting «Actual size / 100%», not «fit to page»).

Check the drilling spot with a detector for electrical, water and gas lines.